

CAPILLARY THERMOSTAT 90°C

This type of control operates by expansion and contraction of a liquid in response to temperature change. Liquid contained within the sensing bulb and capillary flexes a diaphragm, causing the opening and closing of a snap-action switch. For heating applications the contacts are normally closed and open on temperature rise.

Temperature range: 0°C - 90°C

Control Type: SPDT

Relay 15(2,5)A / 250V

Diferential: 2K°+/- 7K

Capillary Length: 1000 mm

Type of connection: Faston



HERTEN S.L.

Cami Hostalassos, 11

12550 Almazora

Castellón

Spain

Telf. 964 21 11 81

Fax. 964 20 73 90

Email: comercial@hertensl.com

www.hertensl.com



CAPILLARY THERMOSTAT 120°C

This type of control operates by expansion and contraction of a liquid in response to temperature change. Liquid contained within the sensing bulb and capillary flexes a diaphragm, causing the opening and closing of a snap-action switch. For heating applications the contacts are normally closed and open on temperature rise.

Temperature range: 0°C - 120°C

Control Type: SPDT

Relay 15(2,5)A / 250V

Diferential: 2K°+/- 7K

Capillary Length: 1000 mm

Type of connection: Faston



HERTEN S.L.

Cami Hostalassos, 11

12550 Almazora

Castellón

Spain

Telf. 964 21 11 81

Fax. 964 20 73 90

Email: comercial@hertensl.com

www.hertensl.com

